

2/16

FIG. 2






FIG. 3




001290"E020E560

FIG. 4






6/16



7/16

FIG. 7



001290-EO20E560



[illegible]



FIG. 9




[illegible]

Diagram illustrating a vertical member 301. Arrows 302, 303, 304, 305, and 306 indicate flow directions. Arrow 302 points upwards from the bottom right. Arrow 303 points downwards from the left. Arrow 304 points upwards and to the right. Arrow 305 points upwards and to the left. Arrow 306 points downwards from the left. A curved line 301a is shown near the bottom of member 301.

11/16


FIG. 11



001250" E020E560

12/16


FIG. 12



09530703-062100

FIG. 13

09530703 062100



14/16

FIG. 14






FIG. 15

FIG. 15





096703-0